



SAFETY NOTES :

- THE STAGE BODY MOVES DURING OPERATION. PLEASE ALLOW A MINIMUM CLEARANCE OF 0,5 mm BETWEEN THE STAGE BODY AND ANY ADJACENT SURFACE.

-DO NOT SQUEEZE THE STAGE BODY

SIZE	THREAD SIZE	INNER DIAMETRE
RMS	W0.8 x 1/36"	14
M25	M25 x 0.75	22
M26	M26 x 1/36"	23
M27	M27 x 0.75	24
M32	M32 x 0.75	29